dreambaby®
growing safely

ASTM F1004.

INSTRUCTIONS:
Mayfair Brooklyn Converta®

F2020 F2030 F2031

Item numbers may also end in BB.

IMPORTANT! READ AND FOLLOW THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

If you sell or give away this product, make sure you give this instruction to the new owner.

⚠ WARNING

Children have died or been seriously injured when enclosures are not securely installed.

- **ALWAYS** install and use enclosures as directed using all required parts.
- **STOP** using when child can climb over or dislodge/open the enclosure.
- Use only with the locking mechanism securely engaged.
- **NEVER** use an enclosure to keep child away from pool.
- **To prevent falls, never use at top of stairs.**

- The surfaces that the enclosure is to be fixed to must be suitable for purpose and structurally sound.
- Intended for use with children from 6 months through 24 months.
- This enclosure has a manual close system.
- This product will not necessarily prevent all accidents. **NEVER** leave child unattended.
- Do not use Play-Pen at the top of stairs
- The Play-Pen is not intended for sleep use.
- Do not place the Play-Pen close to an open fire or other heat source.

* If using this as a fireplace barrier see Instruction manual for minimum distance from heat source.


- This enclosure is intended for indoor use and is not to be exposed to outdoor elements.
- Barrier can be used to create a landing area at the top or base of stairs. Never use at top of stairs directly across top step.
- Discontinue use if gate becomes damaged, broken, or disassembled.
- Do not leave anything in the Play-Pen which may provide a foothold for climbing.
- The safety barrier must not be fitted across windows.
- This barrier is for domestic use only.
- This enclosure is intended for indoor use and is not to be exposed to outdoor elements.
- Do not use this enclosure as a barrier if it can't be installed to walls, door frames or posts – tightly and flatly. DO NOT install to hollow walls.


Fits Openings 3.75m / 147.5in


COMPONENTS


- **A** Gate Panel
- **B** Barrier Panel
- **C** Release Button
- **D** Tension Knobs
- **E** Wall Mount **(x2)**
- **F** Screws **(x8)**
- **G** Masonry Plugs **(x8)**
- **H** One-Way Stopper
- **I** Gate Release Switch
- **J** Connector
  - **J1** -Top of Connector
  - **J2** -Base of Connector
- **K** 2-Way Switch
- **L** Small Spacer
- **M** Large Spacer
- **N** Spacer Screws

Before you start










WARNING: This package contains small parts and sharp points in an unassembled state.
Keep out of reach of children.
Adult assembly required.


WARNING :
F2031 Brooklyn Converta® Gate is NOT SUITABLE for use as a Fireplace Barrier.

F2031 Brooklyn Converta® Gate




TO ASSEMBLE PLAY-PEN


1. Cut tie and unfold Barrier Panels (B) and Gate Panel (A).




2. Push Release Button (C) and 'CLICK' into place.



3. Tighten each Tension Knob (D) after positioning so the Play-Pen is secure. Check the tension before each use.



To Fit Dreambaby® Converta®
Play-Pen Mat
FL962/F2006/F2163)
(sold separately).



WARNING:

Ensure ties are out of reach of children.


TO USE AS BARRIER GATE

1. Choose the best location for mounting Barrier Gate.

Ensure the surface you mount the Gate is structurally sound such as solid timber, brick or masonry.

For plaster/gyprock surface, locate the timber beam or stud behind and mount in this location (mounting on plaster/gyprock alone is not strong enough and not safe). DO NOT MOUNT TO GLASS.

Measure the gap where the gate will be installed.




DECIDE ON THE GATE OPENING DIRECTION

The gate is fitted with a One-Way Stopper **(H)** which restricts the swing to one direction.


It is important to choose which direction you want the gate to swing prior to installation.

Ensure that the position allows for the gate to fully open to enable the Stay-Open feature to work.




Alternatively, replace One-Way Stopper with 2-Way Switch **(K)**.


GATE POSITIONING




Using a MAXIMUM of 3 panels, the gate can be used to create a landing area at the top or base of stairs. To prevent falls, never use at top of stairs, directly across top step.


LANDING AT TOP OF STAIRS






LANDING AT BOTTOM OF STAIRS





Use One-Way Stopper to set direction of gate opening.


Always open door AWAY from stairs.




TO USE AS BARRIER GATE

2. Cut tie and unfold Barrier Panels (B) and Gate Panel (A).


The gate comes with the One-Way Stopper **(H)** fitted. Check gate opening direction before proceeding with installation. Alternatively, replace with 2-Way Switch **(K)**.




3. Assemble Connector (J) by installing Top (J1) and Base (J2).




4. Install Connector (J) to the end Barrier Panel (B).




Push Release Button (C) and "CLICK" into place.






5. Install Wall Mounts (E) to the ends of Barrier Panel. Push Release Button (C) and "CLICK" into place.




TO USE AS BARRIER GATE


6. Position in desired location with Wall Mounts (E) flat against the wall.




FOR WALLS WITH SKIRTING BOARDS

Use Spacers on top wall mount to match depth of the skirting boards.












7. Use pencil to mark screw holes positions.



8. Remove Barrier Gate and drill pilot holes for screws.




FOR TIMBER




NOTE: For plaster/gyprock surface, locate the timber beam or stud behind and mount in this location (mounting on plaster/gyprock alone is not strong enough and not safe).


FOR BRICK/MASONRY




9. Reposition Barrier Gate and screw into place.



10. Tighten each Tension Knob (D) to secure the position.






To reduce movement across a wide span, form a ZIG-ZAG shape with the panels.


* FIREPLACE BARRIER

⚠ WARNING :


- If using this enclosure as a fireplace barrier, ensure it is installed at least **60cm/23.5in** from fire source.
- Regularly check the plastic parts of the barrier.
- Discontinue use if any sign of discolouration or warping.
- If the Barrier is hot to touch, it is too close to fire source. Reinstall Barrier further away from fire source.
- Fireplace door must NOT be LEFT open at any time.




* For built in gas or electric heaters recessed into a fireplace maintain a distance of **60cm/23.5in** from fire source.



- For open, wood burning recessed fireplaces maintain a distance of **80cm/ 31.5in** from the fire source.



- For non-recessed fireplaces that protrude from the wall such as pot belly stoves, a minimum distance of **80cm/31.5in** should be maintained around the entire perimeter of fire source.
- For stoves where the exterior surface temperature can reach temperatures above **260ºC/500ºF** maintain at least **90cm/ 35.5in** distance around the entire perimeter of heat source.




NOTE - For fireplaces with a door, the **distance must be measured** from the outer edge of open door.
Ensure not to leave the door open at any time.

Purchase additional Panels (F2040/F2041/F2061) to achieve recommended distances at www.dream-baby.com


⚠ WARNING : F2031 Brooklyn Converta® Gate is NOT SUITABLE for use as a Fireplace Barrier.

TO REMOVE OR ADD PANELS

TO REMOVE




ADD PANEL




Additional panels are available see **www.dreambaby.com.au**, F2040/F2041/F2061.


GATE OPERATION

Slide the Release Switch **(I)** and lift gate panel **(A)**.
Swing gate closed ensuring locks are engaged.






SMART STAY-OPEN SYSTEM




To engage the Smart Stay-Open System swing gate to its maximum opening. Gate will stay open. Close as required.

Caution: Keep gate closed when children are present.


ONE-WAY STOPPER / 2 WAY SWITCH



Using a Philips screwdriver, remove the screw holding the One-Way Stopper **(H)** in place.



Remove One-Way Stopper **(H)** and replace with the 2 Way Switch **(K)**. Replace the holding screw.



The gate will swing in both directions.

MAINTENANCE & CARE

- Play-Pen/Fireplace Barrier/ Barrier Gate must be fitted according to instructions to ensure it works correctly.
- Regularly check all parts to ensure Play-Pen/Fireplace Barrier/Wide Barrier Gate is secure. Adjust as required.
- To clean, wipe surface with a damp cloth or sponge using mild detergent and warm water. Never clean with abrasive, ammonia based bleach based or spirit type cleaners.
- Only use Dreambaby® spare parts. Any additional and replacement parts should be obtained from Tee-Zed Products.

dreambaby® growing safely

Tee-Zed acknowledges that its customers may be entitled to statutory consumer guarantees and does not seek to exclude or limit them. These guarantees include that Tee-Zed's products are of acceptable quality. This Tee-Zed product is for the specific purpose detailed in the instructions and packaging and Tee-Zed considers use outside of that purpose to be abnormal use. To the maximum extent permitted by law, Tee-Zed does not accept any liability for damage:
- **arising from abnormal use of the products;**
- **caused by installation or removal of the products other than in accordance with the supplied installation and removal instructions; or**
- **arising under the law of tort or contract.**

Made in Zhejiang, China.
©2021 Tee-Zed Products Pty Ltd

Dreambaby® products by Tee-Zed

Tee-Zed Products Pty Ltd
PO Box 2022,
Bondi Junction
NSW 1355
Australia
+61 (0)2 9386 4000
info@tee-zed.com.au
www.dreambaby.com.au

Tee-Zed Products (N.Z.) Ltd
PO Box 64013,
Botany Town Centre
Auckland
New Zealand
+64 (0)9 274 8788
info@tee-zed.co.nz
www.dreambaby.co.nz

Tee-Zed Products Ltd
PO Box 29227,
Dunfermline,
KY12 2DN
United Kingdom
+44 (0)844 800 9445
info@tee-zed.co.uk
www.dreambaby.co.uk

Tee-Zed Products
PO Box 3419
5203DK **NL**
+35314428778
info@tee-zed.eu

dreambabysafety
YouTube dreambabytv

F2020.2030.2031-CONVERTA_IM_p1-p8_19.02.2021_X.02