


OUTLET PLUGS




Dreambaby® Outlet Plugs help prevent children from inserting objects into electrical outlets.

To Install:

Insert Outlet Plugs into all unused electrical outlets.

SAFETY CATCHES



Dreambaby® Safety Catches helps provide easy access for adults but are difficult for young children to open. Suitable for use on the top or side of most cabinets. Suitable for top drawers, may be used on lower drawers where there is a top divider to which the catch may be fitted.


To Install:

1. Install the Catch 2.5cm away from inside edge of the cabinetry frame **A**.
2. Position the Hook to engage the middle of the catch **B**. Ensure maximum opening will not exceed 3cm **B**.
3. Install the hook to the inside of cabinet door or drawer. For easier installation, mark guide holes.

To Use:

Pull open door or drawer slightly. Press down on hook to open **C**. Locks automatically when closed.

MULTI-PURPOSE LATCHES



Dreambaby® Multi-Purpose Latch is suitable for most gloss & laminated, wood or veneer furniture, refrigerators, toilets, glass, mirror, metal cabinets & more.

To Install:

1. Locate the best position to apply product, high above the reach of child.
2. Thoroughly clean and dry surfaces.
3. With product assembled, peel off backing paper. Press firmly into place **A**.
4. Leave for 48 hours to allow adhesive to fully set.

To Use:

To open: Gently pull off the strap from one of the discs, while pressing disc against cabinet **B**.
To close: Press strap back onto the disc, ensuring it is properly engaged **C**.

Regularly check straps for wear and tear.

Replacement straps (F175, 2-pack) sold separately.


To Remove:

Use rubber cement solvent, eucalyptus oil or similar product. Not suitable for reuse.

Warning:

Do not use on appliances which generate heat.
Do not use on oiled surfaces as the adhesive will not stick.
Tape may affect some furniture, not recommended on wax-based finishes.
Before applying, test veneer is securely attached or damage could occur.

DOOR KNOB COVERS




Dreambaby® Door Knob Covers will help prevent curious toddlers from accessing potentially dangerous areas such as the laundry, bathroom, garage, basement or storage rooms. Fits most standard door knobs.

To Use:

1. Open cover, position over door knob and snap closed **A**.
2. To open door grip discs 1 on either side of the cover **B**.
3. Squeeze and turn door knob **C**.
4. For door knobs with push button locks, open the lid 2 to access.

SLIDING LOCKS



Dreambaby® Sliding Locks easily fit to cabinet knobs or D-Shaped handles. Closes with a simple sliding action, helping keep children out of cabinets. We recommend use on handles no further than 11.4cm apart.

To Use:

1. Pressing top and bottom buttons simultaneously, slide catch toward the open end.
2. Insert rod over the knobs **A** or through the handles **B**.
3. Slide the catch inward to tighten. Sliding catch will lock in place.
4. To remove, repeat step 1.

Tee-Zed acknowledges that its customers may be entitled to statutory consumer guarantees and does not seek to exclude or limit them. These guarantees include that Tee-Zed's products are of acceptable quality. This Tee-Zed product is for the specific purpose detailed in the instructions and packaging and Tee-Zed considers use outside of that purpose to be abnormal use. To the maximum extent permitted by law, Tee-Zed does not accept any liability for damage:

- arising from abnormal use of the products;
- caused by installation or removal of the products other than in accordance with the supplied installation and removal instructions; or
- arising under the law of tort or contract.

Tee-Zed Products Pty Ltd
PO Box 2022,
Bondi Junction NSW 1355
AU ☎ +61 (0)2 9386 4000
✉ info@tee-zed.com.au
www.dreambaby.com.au

Tee-Zed Products (N.Z.) Ltd
PO Box 64013,
Botany Town Centre
Auckland
NZ ☎ +64 (0)9 274 8788
✉ info@tee-zed.co.nz
www.dreambaby.co.nz

Tee-Zed Products Ltd
PO Box 29227,
Dunfermline, KY12 2DN
UK ☎ +44 (0)844 800 9445
✉ info@tee-zed.co.uk
www.dreambaby.co.uk

Tee-Zed Products (EU) Ltd
PO Box 3419, 5203DK NL
☎ +35314428778
✉ info@tee-zed.eu

Warning: All dangerous substances and objects must always be kept high up or in an area totally inaccessible to children. There is no substitute for proper adult supervision. This product is only a deterrent. Discontinue use when child is able to open or remove it.